

LOBADUR[®] WS Viva



Product description

One-component waterborne finish for parquet and hardwood floors.

Range of Use:

Parquet and hardwood floors with normal to heavy wear.
Good chemical resistance.

Features

- safe and easy application
- balanced features
- excellent price-performance ratio

Technical Data

Article No.	11519	Application Rate	Each roller application 100 - 120 ml/m ² (8 - 10 m ² /l)
Gloss level	satin (ca. 20*) semi-gloss (ca. 33*) The gloss level is measured at 60°. It depends on the thickness and the climatic conditions (temp, rel. Air humidity) during drying. The data is not binding.	Application Tool	LOBATOOL roller DeLuxe 120 LOBATOOL roller Microfaser 100 - 120
Package Size	satin 10l, 5l semi-gloss 10l, 5l, 1l	Drying Time	Earliest possible recoating after 4-6 h Can be carefully walked on after 4-6 h Earliest possible intermediate sanding after 8-10 h Light wear after 24 h Final hardness after 5 days
Packing	Box: 1 x 10 l Pallet: 60 x 10 l Box: 4 x 5 l Pallet: 128 x 5 l Box: 12 x 1 l Pallet: 480 x 1 l	Intermediate Sanding	LOBATOOL Perforated Pad P120 or finer Alternatively Sanding Net P120 or finer. Able to recoat without intermediate sanding within the first 24 hours. After this time an intermediate sanding is necessary. An intermediate sanding before the last application will achieve an even surface.
Solids	34 ± 1%	Thinner	The finish is ready-to-use and cannot be diluted!
Viscosity DIN 4	23 ± 1s		
Storage and Transportation	+5°C to +25°C (41°F to 77°F), storable for 12 months, not a hazardous material according to ADR		
GISCODE	W3+		

VOC

2004/42/CE

EU limit value for this product (cat. A/i): 140g/l (2007/2010)

This product satin contains max. 80g/l VOC

semi-gloss contains max. 80g/l VOC



Technical Information

LOBADUR[®] WS Viva

Information on Use for:

- Shake material well
 - Do not put material directly on the floor, use a LOBATool sealing bucket.
 - regard safety regulations
 - Regard climatic conditions*
 - Ventilate working area *
- *)Regard General Information on the use of waterborne LOBADUR[®] products

Setup recommendations for parquet and hardwood floorings:

1. Prepare and prime surface
2. Drying of primer acc. to technical information
3. Apply WS Viva by using a roller
4. Drying 8 – 10 h
5. Intermediate Sanding
6. Apply WS Viva by using a roller

Use of Primer is Recommended to minimize side-bonding with locking effect for tropical wood, to achieve a color reinforcement of the wood:

- WS EasyPrime
- HS GlobaSeal
- PrimaSeal (solvent based)

The general Information on the Use and maintenance of waterborne LOBADUR[®] Products are part of this Information and must be noticed.